



PCI-E Network Adapter, 2-Port, 10-GbE

Quick Installation Guide

Has (2) RJ-45 10-GbE ports or (2) SFP+ 10-GbE ports.



To download the most recent drivers for the adapter, go to blackbox.com, enter LH3000 or LH3001 in the search box, click on the "Resources" tab, then select the item you wish to download.

Customer Support Information Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. call 724-746-5500) • FREE technical support 24 hours a day, 7 days a week: Call 724-746-5500 or fax 724-746-0746 • Mailing address: Black Box Corporation, 1000 Park Drive, Lawrence, PA 15055-1018 Web site: www.blackbox.com • E-mail: info@blackbox.com

Ouick Installation Guide

CAUTION: Turn off and unplug the power before removing the computer's cover.

Failure to do so could endanger you and may damage the adapter or computer.

STEP 1.

Turn off the computer and unplug the power cord. For hot-plug servers, see your server documentation first.

STEP 2.

Remove the cover bracket from a PCI-Express slot (v1.0a or newer) or a PCI (2.2 or later) slot. If you have configuration problems, see your computer's documentation to determine if the PCI-Express or PCI slots are bus master-enabled.


STFP 3

NOTE: This is an optional step for low-profile-capable models:

If you need to install the adapter in a low profile PCI-Express or PCI chassis, first replace the adapter standard bracket with the supplied low-profile bracket. To remove the existing bracket, unscrew the two screws as shown in the diagram on the next page and then pull the bracket off. Reverse the process to attach the low profile bracket.

STEP 4.

Firmly insert the adapter into the selected slot. Push down to ensure the adapter is fully seated. If you install the adapter in a PCI-Express or PCI slot, make sure the exposed end of the connector does not touch any part of the motherboard. Secure the bracket to the chassis.



STFP 5

Replace the computer cover and plug in the power cord.

STEP 6.


Connect the network cable. The copper model (LH3000) is shown below. The fiber model (LH3001) installs in a similar way, but it has fiber SFP+ slots that accept an SFP+ module and attaches to fiber cable via the module's fiber connectors.

LH3000 (copper model):

- For 10-Gbps operation (10GBASE-T), use category 6 or better cable with 4-pair wiring, different pitches).
- Insert the twisted-pair, RJ-45 network connector as shown.
- For 1000-Mbps operation (100BASE-T), use Category 5 or better cable with 4-pair wiring.
- For 100-Mbps operation (100BASE-TX), use Category 5 or better cable.s

NOTES:

- 1. Maximum length is 328 feet (100 meters).
- The adapter must be connected to a compatible link partner that has the same configuration.



LH3001 (fiber model):

• For the SFP+ slot, remove and save the fiber optic connector cover. Insert a matching fiber optic connector module into the SFP+ slot on the adapter.

The table below lists the compatible SFP+ modules:

Compatible SFP+ modules

	Product Code	Description
	LSP422	10GBASE-SR SFP+, 1310-nm Single-Mode, 10 km, LC
	LSP421	10GBASE-SR SFP+, 850-nm Multimode, 300 m, LC

NOTE: For LC adapters, converter patch cables are available to allow plugging into an SC type connector.

 Most connectors and ports are keyed for proper orientation. If the cable you are using is not keyed, check to be sure the connector is oriented properly.

STEP 7.

Install the adapter drivers.

• Start the computer.

NOTE: You must have administrative rights to the operating system to install the drivers.

- For Windows® 2000, XP, Windows 7, Vista®, Server 2003, and Server 2008, the adapter is detected and Windows either installs a resident driver or starts the "Found New Hardware" wizard. If a resident driver installs (wizard does not appear), update the driver by inserting the cover-mounted CD.
- For Windows NT 4.0, Linux, NetWare®, UnixWare, FreeBSD, and other operating systems: Refer to the driver link on the "Resources" tab (described on the next page)

To download the latest software drivers or this quick installation guide from the Web site:

- 1. Go to www.blackbox.com
- 2. Enter LH3000 or LH3001 in the search box:




3. Click on the "Resources" tab on the product page, and select the drivers and/or documents you wish to download.

Ethernet Address



The Port A Ethernet address is printed on the bar code label on the adapter. Add one hexadecimal to this value to obtain the next port address. For example, Port B would be 0002B3002B51, Port C would be 0002B3002B52, and Port D would be 0002B3002B53.

LEDs on the Adapter



Black Box Tech Support: FREE! Live. 24/7.



Great tech support is just 60 seconds away at 724-746-5500 or blackbox.com.



About Black Box

Black Box provides an extensive range of networking and infrastructure products. You'll find everything from cabinets and racks and power and surge protection products to media converters and Ethernet switches all supported by free, live 24/7 Tech support available in 60 seconds or less.

© Copyright 2014. Black Box Corporation. All rights reserved. Black Box® and the Double Diamond logo are registered trademarks of BB Technologies, Inc. Any third-party trademarks appearing in this manual are acknowledged to be the property of their respective owners.

LH3000, Quick Start Guide, version 1